

DJ EQUIPMENT INFORMATION

- 3 x Pioneer DJ CDJ-3000 professional DJ multi players.
- 1 x Pioneer DJ DJM-900NXS2 4-channel professional DJ mixer.
- 1 x Pioneer DJ DJS-1000 DJ sampler.
- 1 x Pioneer DJ RMX-1000 remix station.
- All of the above equipment linked through an 8-port/1-gigabit network switch with Cat5e/Cat6 cables.
- DJM-900NXS2 4-channel mixer must be updated to the latest firmware [Link to update](#).
- All CDJ-3000 professional DJ multi players must be updated to the latest firmware [Link to update](#).
- DJS-1000 DJ sampler must be updated to the latest firmware [Link to update](#).
- All CDJ-3000 to be connected **DIGITAL AND ANALOG** to the DJM-900NSX2 mixer.

DJ EQUIPMENT LAYOUT SCHEMATIC

TOP VIEW

Gigabit Network Switch



Remix station



R M X - 1 0 0 0

Player 1



CD J - 3 0 0 0

Player 2



CD J - 3 0 0 0

Mixer



D J M - 9 0 0 N X S 2

Player 3



CD J - 3 0 0 0

Player 4



D J S - 1 0 0 0

BACK VIEW

Remix station



Player 4



Player 3



Mixer



Player 2



Player 1



Gigabit Network Switch



Analog (RCA)

Digital (Coaxial)

Cat5 (RJ45)

1/4" Jack